

Aspire Dash Cams

POWERED BY FLEETSHARP

Increase accountability and protect your fleet with the ability to capture video inside and outside your vehicles.

Monitor the safety of your crews while protecting your vehicles.

Dash cams not only record inside and outside your vehicles but also sync with FleetSharp GPS to mark where recordings are captured, providing accurate data that enables you to better manage your crews and protect your vehicles.



Ensure your drivers are practicing safe driving habits.

Quickly view videos from the interior or exterior of your vehicles in the event of an incident, such as a collision or broken glass. Dash cams also allow you to monitor events based on custom parameters, including speeding and harsh braking alerts, so you can determine the cause and address instances of distracted or unsafe driving.

Protect your fleet 24/7, even when the engines are off.

Unlike other dash cams, FleetSharp units protect your vehicles even when unoccupied. Within minutes of the ignition being turned off, the dash cam units automatically enter 'guard' mode. If movement or breaking glass is detected, the camera's LED lights light up the vehicle interior and begin recording. Footage can be saved and sent to police and insurance for verification purposes.

Effortlessly record videos of the interior and exterior of your vehicles.

Record up to 45 rolling hours of engine-on time when using both the internal and external cameras. All video footage, including snapshots and clips generated by alerts, is easily accessible for review within Fleetsharp. Recordings you choose to save to the video library are available for viewing or downloading to your computer for 60 days.

Enable voice-activated recording of incidents.

Allow your drivers to simply say "Okay, Presto" for hands-free recording of short video clips (10 seconds before and 10 seconds after) to capture incidents that would not normally trigger an alert in the system, such as being cut off by another vehicle.

View live video at any time.

4G LTE connectivity allows you to view live video at any time, and all recorded footage is uploaded to the cloud where it's accessible directly within the FleetSharp portal.